

HANDLING

- › Do not sit on the insert
- › Do not drop the insert on the floor and avoid other hard shock(s)
- › Do a visual inspection of the insert every six-month
- › In case of visual damages, send the insert back for inspection / repair
- › Do only clean with pure water or mild soap

GUARANTEE PERIOD

The plate is expected to preserve its conformity with the specifications for a period of at least 5 years during storage from the date of delivery, provided that:

- › The product is stored under dry conditions at normal ambient temperature
- › The product is stored vertically
- › The product has not been subjected to peak temperature exceeding 70°C
- › The product is protected against long term direct exposure to sun light